Philips
CD/DVD Cleaner

Wet system

SAC2570W

Clean your CD player's lens

Regular cleaning of your CD player's lens ensures optimum performance of your equipment. It is important to keep a CD player optical laser lens clean and dust free. This wet system safely removes dust, debris and other contaminants.

Maintain original sound quality

- Wet system

PHILIPS

CD/DVD Cleaner
Wet system

SAC2570W/27

Specifications

Packaging dimensions
- Packaging dimensions (W x H x D): 15.9 x 24.8 x 2.5 cm
- Nett weight: .108 kg
- Gross weight: .118 kg
- Tare weight: .01 kg

Outer Carton
- Outer carton (L x W x H): 54.8 x 34.3 x 36.8 cm
- Nett weight: 7.776 kg
- Gross weight: 8.49 kg
- Tare weight: .714 kg

Inner Carton
- Inner carton (L x W x H): 27.3 x 16.3 x 12.5 cm
- Nett weight: .648 kg
- Gross weight: .7 kg
- Tare weight: .052 kg

Highlights

Wet system
The specially formulated fluid is applied to the brush on the CD lens cleaner. Then the disc is inserted into the CD player and "played".

Issue date 2014-02-07

Version: 1.1.2

12 NC: 8670 000 34797
UPC: 6 09585 14461 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com